
## **TRANSFORMER INSTRUCTION SHEET**


Below are a range of connection options depending on which version you may have. UNPLUG THE TRANSFORMER BEFORE INTERACTING WITH THE FAN HOUSING AND TERMINALS.


# STRIPPED WIRE CONNECTOR

**FAN TYPE** 




### **NEW TRANSFORMER -> FAN WITH CONNECTOR**







#### **NEW TRANSFORMER -> FAN WITH STRIPPED WIRE**




#### **OLD TRANSFORMER-> FAN WITH CONNECTOR**



2. Insert the stripped cable into the terminal block on the fan cover. Power on the fan to test the connection



3. Insert the bug Mesh and fan into the housing. Power on the fan to test the connection. Screw the cover onto the fan housing.





Purchase a new transformer online

Purchase a new fan online