



1. Check this template is correctly scaled by measuring length and width as shown. Replace this template if the dimension is ± 1mm (0.04"). This template is the minimum clearance from wall.

2. Place the template on the floor in the approximate position, then place the pedestal on the template and confirm the pedestal location is suitable.

Check no joists, pipes or cables are under the cut area.

3. Align template to the pedestal by matching the hatched pattern to the internal pedestal hole. Keep the template axis square to the wall.

4. Pin or tape template to the floor, then remove the pedestal.

5. Cut out hole along the outer ring, keeping the cut within the line width (or scribe through the template to mark the floor if the cut cannot be made with the template in position.)

6. Insert chute to check hole shape.

NL-P-200-01-A3_Rev2

FRONT OF PALISADE PEDESTAL A3 FLOOR TEMPLATE